






## INSTALLATION INSTRUCTIONS

### CANTILEVER

- C1 MTB contoured
- C2 Eagle 2™
- C3 Thinline™
- C5 Phat Padd™
- H6 Cross Holder (R4 + R7)



- Clean rim surface before installing new pads.
- Place new pads and finger tighten nuts.
- Align the pads correctly without touching the tire.
- Now tighten the nut with a force of 8-9 Nm.
- Check pad and rim alignment after the pads are broken in and after every ride.

**IMPORTANT:** Designed for bicycle use only. Do not ride bike until brakes are checked and functioning properly. All Kool Stop Pads meet or exceed C.P.S.C. and D.I.N bicycle standards.